

# WallsONE

## Oggi

### Installation & Maintenance Instructions

Oggi Wallcoverings are handcrafted designs. Though extreme care is taken during manufacturing, variations in shade and texture are to be expected. Final inspections are the responsibility of the user.

THE INSTALLER SHOULD STEP BACK AND EXAMINE THE WALLCOVERING AFTER EVERY FEW STRIPS TO ENSURE THE DESIRED EFFECT IS ACHIEVED.

Walls One  
1200 Arthur Avenue  
Elk Grove, Illinois 60007  
tel 224.366.5100  
fax 224.366.5111  
www.wallsone.com

**Check Before Cutting:** Before cutting and hanging, check pattern name and number to match products ordered. NO CREDIT for labor charges will be allowed for cutting or hanging wrong colorways or patterns. Be sure that there is sufficient material to complete the job. Should you have any questions, contact WallsOne customer service at (224)366-5100 before proceeding. **NO RETURNS will be accepted after the material is cut.**

**Wall Preparation:** Previous wallcovering must be removed. Walls must be structurally sound, dry, sealed and clean prior to installation. Wall surfaces shall be free from defects and imperfections that could show through the finished covered surface. Prime with a high quality acrylic wallcovering primer.

**Trimming:** Handcrafted wallcoverings are shipped untrimmed. Take care to accurately table trim the edge of each sheet. Be sure edges are even before installation. Each shipment contains bolts marked with consecutive numbers. This is the order in which the product was manufactured and should be followed in installation.

**Adhesive:** You MUST use a high wet tack heavy-duty clear strippable adhesive. Do not dilute. Using another type of adhesive will be solely at the risk of the installer. Solari wallcoverings are not strippable or peelable. Apply an even coat of adhesive to the back of the wallcovering. Allow the adhesive to become tacky before applying to wall. The material should be allowed to book for a suitable time (approx. 15-20 minutes) prior to installation. Be cautious not to allow adhesive to touch the face of the goods.

**Test Hanging:** Test hang three panels and carefully review materials and application. If satisfactory, continue the installation. If not, contact WallsOne customer service at (224)366-5100.

**WallsOne assumes no responsibility for the installation of material beyond three panels. Under no circumstances will WallsOne be responsible for labor.**

**Installation:** **Wallcovering shall be installed by experienced workers and contractors in strict accordance with these instructions.**

Material must be dry table trimmed. **Do not double cut.** Apply material to wall using a soft brush or plastic smoother. Examine smoothing brush often, as an accumulation of paste on tools may mark or scratch the material. Completely clean adhesive off the surface after each strip is hung. Wash seams with a damp sponge and clean warm water. Change rinse water often. Any adhesive left on the surface can cause flaking. Dry carefully with a soft cloth or chamois.

**Maintenance:** Stains can be removed when immediately wiped of with a clean sponge or rag (slightly damp). Use a mild soap or detergent to clean the wallcovering. Do not soak. Avoid excess rubbing or pressure so as to not damage the finish.